



User Manual

Digital Kitchen Scale

Model: EK8060



Questions or Concerns?

Mon-Fri, 9:00 am-5:00 pm PST/PDT
support@etekcity.com • (855) 686-3835

Thank you for purchasing the Digital Kitchen Scale by Etekcitizens.

If you have any questions or concerns, please reach out to our helpful Customer Support Team at support@etekcity.com. We hope you enjoy your new kitchen scale!

Become an Etekcitizen

Get exclusive deals, giveaways, and product registration.
Better products for better living.
Find us at etekcity.com

Table of Contents

Package Contents	3	Replacing the Batteries	9
Specifications	3	Troubleshooting	10
Important Safety Information	4	Warranty Information	11
Function Diagram	5	Customer Support	13
Before First Use	6		
Symbols	7		
Using Your Scale	7		
• General Operation	7		
• Zero / Tare Function	8		
• Unit Conversion	9		
• Automatic Power Off	9		
• Manual Power Off	9		

Package Contents

1 x Digital Kitchen Scale
2 x 3V CR 2032 Batteries (Pre-Installed)
1 x Quick Start Guide

Specifications

Weight Capacity	176 oz / 11 lb / 5000 g / 5000 mL
Units	oz / lb:oz / fl oz (water/milk) / g / mL (water/milk)
Increments	0.04 oz / 1 g / 1 mL
Auto-Off	180 seconds
Battery	2 x 3V CR 2032 batteries
Dimensions	8.3 x 6.3 x 0.6 in / 21 x 16 x 1.6 cm

Important Safety Information

To avoid damage to this scale, please read and follow all instructions and safety guidelines in this manual.

Scale

- **Always** place the scale on a hard, dry, and flat surface before measurement in order to ensure accuracy.
- **Do not** exceed the 11 lb / 5000 g weight capacity as it will damage the scale. An error indicator will appear on the LCD display if the limit is exceeded.
- **Do not** immerse the scale in water or any liquid. If liquid is spilled on the digital display or buttons, immediately wipe the scale dry with a soft cloth to avoid internal damage.
- Handle with care. This scale is not intended for commercial or heavy-duty use.
- Keep the scale in a cool, dry place. Avoid exposure to damp environments or extreme temperatures.
- Household use **only**.


Batteries

- **Do not** mix new and old batteries.
- If the low battery indicator “  ” appears on the display, replace the batteries.
- If the scale is not in use for an extended period of time, remove the batteries to conserve battery life and extend the lifetime of the scale.

SAVE THESE INSTRUCTIONS

Function Diagram

- A.** Unit Selection Button
- B.** LCD Display
- C.** Power/Tare Button
- D.** Battery Compartment
- E.** Screw
- F.** Anti-Skid Pads



Before First Use

Note: The batteries are pre-installed in the scale.

1. Turn the scale over, remove the screw, and open the battery compartment.
2. Remove the plastic strip from the battery compartment. *[Figure 1.1]*
3. Replace the battery compartment cover.
4. Turn the scale back over and place on a hard, dry, flat surface.
5. Press  TARE to turn on the scale.




Figure 1.1

Symbols



Solids



Water (Liquid)



Milk

Using Your Scale

Note:

- For accurate results, **always** place the scale on a hard, dry, flat surface, and keep the scale away from dirt, dust, vibrations, wind, air currents, and electromagnetic interference.
- When you turn on the scale, choose units, or use the tare function, wait for the display to read **000** before measuring.

General Operation

1. Place the scale on a hard, flat, level surface.
2. Press  **TARE** to turn on the scale. Make sure the display reads **000**. Press **UNIT** to select your desired measuring unit, which will show on the right of the display.
3. Place your item on the scale.
4. Wait for the reading on the display to stabilize.

Zero / Tare Function

Whenever you measure items inside a container, you can use the tare function to remove the container's weight from the final measurement.

1. Press  **TARE** to turn on the scale. Make sure the display reads **000**. If the screen does not display **000** automatically, press  **TARE** to auto-adjust to zero.
2. Place the container on the center of the scale.
3. Wait for the reading on the display to stabilize. The display will show the container's weight.
4. Press  **TARE** to tare the weight of the container. The screen should now display **000**.
5. Place the liquid or items into the container. The scale will measure the contents without including the weight of the container. *[Figure 2.1]*
6. When you're done, reset the scale by removing all weight and pressing  **TARE** again.




Figure 2.1

Unit Conversion

To change the unit of measurement, press **UNIT** until the display shows the desired unit of measurement.

Automatic Power Off

To save battery power, the scale will automatically power off after 180 seconds of inactivity.

Manual Power Off

Press and hold  **TARE** for 2 seconds to turn off the scale.

Replacing the Batteries

1. Turn the scale over and open the battery compartment.
2. Take out the used batteries and replace them with 2 new 3V CR 2032 batteries.
3. Replace the battery compartment cover and screw it shut.

Troubleshooting

Problem	Possible Solution
Scale does not turn on.	Open the battery compartment cover and remove the plastic strip.
	Replace the batteries (see page 9).
	Make sure batteries are inserted under the correct polarity as marked in the battery compartment.
Reading is inaccurate.	Place scale on a level surface.
	Make sure the screen displays 000 before measuring (see Zero / Tare Function , page 8).
	Remove the batteries for 45 seconds, then replace them to reset the scale.
Display shows EEEE	Item is too heavy. Remove item from scale to protect its weight sensors. Use a different scale with a higher weight range.
Display shows Err	Calibration error. Turn the scale off and on again. Avoid moving the scale while measuring.
Display shows LO	Battery power is low. Replace the batteries (see page 9).

If your problem is not listed, please contact **Customer Support** (see page 13).

Warranty Information

Product	<i>Digital Kitchen Scale</i>
Model	<i>EK8060</i>
Default Warranty Period	<i>1 year</i>
For your own reference, we strongly recommend that you record your order ID and date of purchase.	

Terms & Policy

Etekcitey Corporation warrants all products to be of the highest quality in material, craftsmanship, and service, effective from the date of purchase to the end of the warranty period.

Etekcitey Corporation will replace any product found to be defective due to manufacturer flaws based on eligibility. Refunds are available within the first 30 days of purchase. Refunds are only available to the original purchaser of the product. This warranty extends only to personal use and does not extend to any product that has been used for commercial, rental, or any other use in which the product is not intended for. There are no warranties other than the warranties expressly set forth with each product.

This warranty is non-transferrable. Etekcitey Corporation is not responsible in any way for any damages, losses, or inconveniences caused by equipment failure or by user negligence, abuse, or use noncompliant with the user manual or any additional safety or use warnings included in the product packaging and manual.

This warranty does not apply to the following:

- Damage due to abuse, accident, alteration, misuse, tampering, or vandalism.
- Improper or inadequate maintenance.
- Damage in return transit.
- Unsupervised use by children under 18 years of age.

Etekcitey Corporation and its subsidiaries assume no liability for damage caused by the use of the product other than for its intended use or as instructed in the user manual. Some states do not allow this exclusion or limitation of incidental or consequential losses so the foregoing disclaimer may not apply to you. This warranty gives you specific legal rights and you may also have other rights which may vary from state to state.

ALL EXPRESSED AND IMPLIED WARRANTIES, INCLUDING THE WARRANTY OF MERCHANTABILITY, ARE LIMITED TO THE PERIOD OF THE LIMITED WARRANTY.

Additional 1-Year Warranty

You can extend your 1-year warranty by an additional year. Log onto **www.etekcity.com/warranty** to register your new product for the extended warranty.

Please fill out all required fields and include your order ID, place of purchase, and purchase date, if applicable.

Defective Products & Returns

If you discover your product is defective within the specified warranty period, please contact Customer Support via **support@etekcity.com** with a copy of your invoice and order ID. **DO NOT** dispose of your product before contacting us. Once our Customer Support Team has approved your request, please return the product with a copy of the invoice and order ID.



Customer Support

If you have any questions or concerns about your new product, please contact our helpful Customer Support Team.

CUSTOMER SUPPORT

Etekcitey Corporation

1202 N. Miller St., Suite A
Anaheim, CA 92806

Email: support@etekcity.com

Toll-Free: (855) 686-3835

SUPPORT HOURS

Mon-Fri, 9:00 am-5:00 pm PST/PDT

**Please have your order invoice and order ID ready before contacting Customer Support.*



Connect with us @Etekcity



